# **THERMOWASHER**

# WASHER TO FASTEN INSULATION TO TIMBER

#### CE FASTENING WITH HBS SCREWS

The THERMOWASHER is intended for use with screws with the CE marking in accordance with ETA. Ideal for  $\emptyset$ 6 or  $\emptyset$ 8 HBS screws, with lengths based on the thickness of the insulation to be fastened.

#### ANTI-THERMAL BRIDGE

Incorporated hole cover to avoid thermal bridges. Large cable spaces for proper plaster adhesion. Has a system that prevents the screw from pulling out.



# CODES AND DIMENSIONS

CODE	d <sub>SCREW</sub>	a x b x c	pcs
	[mm]	[mm]	
THERMO65	6/8	65 x 4 x 20	700





## MATERIAL Propylene (PP) system.

### FIELDS OF USE

The  $\emptyset$ 65 propylene washer is compatible with  $\emptyset$ 6 and  $\emptyset$ 8 screws; it is suitable for any type of insulation and any type of fixture thickness.